Programme After Market Services (PAMS)
Technical Documentation

NHB–3 QUICK GUIDE

AMENDMENT RECORD SHEET

Amendment Number	Date	Inserted By	Comments

QUICK GUIDE

Contents

Quick Guide Page 4
General Page 4
Memory Page 4
Menu Page 4
Menu Functions (accessible by menu or shortcut) Page 5

Quick Guide

General

– Make a call	Area code, phone number talk
– End a call	end
– Answer a call	talk
– Clear the display	Press and hold **CLR**
– Last number redial	talk
– Single key dialling	Press and hold location number (1–9)
– Mute/unmute	Press and hold **MENU**
– Hold/unlock/swap	Move the pointer, press **OK**
– Lock/unlock keybad	**MENU ***
– Speed diallling	Location number talk
– Adjust earpiece	Use the side buttons: upper increases, lower decreases
– Emergency services	Emegency number talk

Memory

– Store a number (in first avail. loc.)	Area code, number, **MEMORY**
– Search for a number	∧ or v
– Search for a name	**ABC** ∧ or v

Menu

– Enter menu	**MENU**
– Scroll functions	∧ or v
– Select displayed function	**SELECT**
– Scroll options	∧ or v select option, **OK**
– Shortcut (see list below)	**MENU** *Function number*
– Return to title screen	**QUIT**
– Exit menu	**CLR**

Menu Functions (accessible by menu or shortcut)

Shortcut	Function	Description
Menu 1	Recent calls	Shows last dialled, receive and missed calls.
Menu 2	Messages	Read, write, listen and send messages.
Menu 3	Call divert	Diverts calls to another number.
Menu 4	Phone settings	Set lights, ringing volume, tones, any key answer, DTMF, autom. redial, language, autom. answer, power off, battery save.
Menu 5	Security	Sets PIN code, security level, call barring.
Menu 6	Duration costs	Show or clears call timers.
Menu 8	Memory options	Select, erase, copy memory.
Menu 9	Personal reminder	Control accessories.
Menu 10	In call options	Mute, drop, swap, hold calls, send DTMF.
Menu 11	Fax/Data	Sends and receives data.
Menu 12	Number editor	Displays the SIM card phone number.
Menu 13	Ring options	Sets all tones on or off.

This page intentionally left blank.